

**HANDY PUNCH®
PATTERN SET M1007**

THESE PATTERNS ARE SUITABLE
FOR USE WITH KNITMASTER MACHINES
MODELS 313, 321, 323, 325.


Empireal
Knitmaster




M121



M122




M123




M124




M125




M126




M127



M128



M129




M130


**HANDY PUNCH®
PATTERN SET M1007**

THESE PATTERNS ARE SUITABLE
FOR USE WITH KNITMASTER MACHINES
MODELS 313, 321, 323, 325.


Empireal
Knitmaster



M131




M132




M133




M134




M135



M136




M137




M138




M139



M140





HANDY PUNCH PATTERN \triangle top


M 122
©

CUT HERE


HANDY PUNCH PATTERN Δ top


M 123


©




CUT HERE











CUT HERE



HANDY PUNCH PATTERN Δ top

M 129
©




CUT HERE

HANDY PUNCH PATTERN Δ top

M 130


©





CUT HERE




CUT HERE











CUT HERE




HANDY PUNCH PATTERN Δ top



M 136



CUT HERE



HANDY PUNCH PATTERN [△]top

© M 138

