



**HANDY PUNCH ©
PATTERN SET M 1013**

THESE PATTERNS ARE SUITABLE
FOR USE WITH KNITMASTER MACHINES
MODELS 321, 323.


Empisal
Knitmaster




M221




M222




M223




M224




M225



M226



M227




M228


**HANDY PUNCH ©
PATTERN SET M 1013**

THESE PATTERNS ARE SUITABLE
FOR USE WITH KNITMASTER MACHINES
MODELS 321, 323.


Empisal
Knitmaster




M229




M230




M231




M232




M233




M234




M235




M236




M237



M238



M239



M240

